

Panasonic QUICK INSTRUCTION MANUAL

Safety Light Curtain Type 4 SF4D Series

ME-SF4D No.0102-79V

Thank you very much for purchasing this Panasonic product. Please read this Instruction Manual carefully and thoroughly for the correct and optimum use of this product. Kindly keep this manual in a convenient place for quick reference.

- This document provides brief explanations of mounting and wiring. For detailed handling information, refer "our web site: <https://industry.panasonic.com/>".
- Instruction Manuals in the following languages are available on our Website. Japanese, English, Chinese, Korean (excludes the SF4D--01), French, German, Spanish (excludes the SF4D--01), Polish

1 SAFETY CAUTIONS (Always observe)

- This section explains important rules that must be observed to prevent human injury and property damage.
 - The hazards that may occur if the product is used incorrectly are described and classified by level of harm.

WARNING Risk of death or serious injury.

CAUTION Risk of minor injury or property damage.

- Use this device as per its specifications. Do not modify this device since its functions and capabilities may not be maintained and it may malfunction.
- This device has been developed / produced for industrial use only.
- This device is suitable for indoor use only.
- Use of this device under the following conditions or environments is not presupposed. Please consult us if there is no other choice but to use this device in such an environment.

- Operating this device under conditions or environments not described in this manual.
 - Using this device in the following fields: nuclear power control, railroad, aircraft, auto mobiles, combustion facilities, medical systems, aerospace development, etc.
- When this device is to be used for enforcing protection of a person from any danger occurring around an operating machine, the user should satisfy the regulations established by national or regional security committees (Occupational Safety and Health Administration: OSHA, the European Standardization Committee, etc.). Contact the relative organization(s) for details.

- In case of installing this device to a particular machine, follow the safety regulations in regard to appropriate usage, mounting (installation), operation and maintenance. The users including the installation operator are responsible for the introduction of this device.
- Note that this device may be damaged if it is subject to a strong shock (if it is dropped onto the floor, for example).
- Use this device by installing suitable protection equipment as a countermeasure for failure, damage, or malfunction of this device.

- Before using this device, check whether the device performs properly with the functions and capabilities as per the design specifications.
- In case of disposal, dispose this device as an industrial waste.
- Do not use this product with mobile equipment such as an automated guided vehicle (AGV).

WARNING

- Machine designer, installer, employer and operator**
 - The machine designer, installer, employer and operator are solely responsible to ensure that all applicable legal requirements relating to the installation and the use in any application are satisfied and all instructions for installation and maintenance contained in the instruction manual are followed.
 - Whether this device functions as intended and systems including this device comply with safety regulations depends on the appropriateness of the application, installation, maintenance and operation. The machine designer, installer, employer and operator are solely responsible for these items.

- Engineer**
 - The engineer would be a person who is appropriately educated, has wide-spread knowledge and experience, and can solve various problems which may arise during work, such as a machine designer, installer or employer etc.

- Operator**
 - The operator should read this instruction manual thoroughly, understand its contents, and perform operations following the procedures described in this manual for the correct operation of this device.
 - In case this device does not perform properly, the operator should report this to the person in charge and stop the machine operation immediately. The machine must not be operated until correct performance of this device has been confirmed.

- Environment**
 - Do not use a mobile phone or a radio phone near this device.
 - If there exists a reflective surface in the place where this device is to be installed, make sure to install this device so that reflected light from the reflective surface does not enter into the receiver, or take countermeasures such as painting, masking, roughening, or changing the material of the reflective surface, etc. Failure to do so may cause the device not to detect, resulting in death or serious injury.
 - Do not install this device in the following places:
 - Areas exposed to intense interference (extraneous) light such as high-frequency fluorescent lamp (inverter type), rapid starter fluorescent lamp, stroboscopic lights or direct sunlight
 - Areas with high humidity where condensation is likely to occur
 - Areas exposed to corrosive or explosive gases
 - Areas exposed to vibration or shock of levels higher than that specified
 - Areas exposed to contact with water
 - Areas exposed to too much steam or dust

- Installation**
 - Always keep the correctly calculated safety distance between this device and the dangerous parts of the machine.
 - Install extra protection structure around the machine so that the operator must pass through the sensing area of this device to reach the dangerous parts of the machine.
 - Install this device such that some part of the operator's body always remains in the sensing area when operator is done with the dangerous parts of the machine.
 - Do not install this device at a location where it can be affected by wall reflection.
 - When installing multiple sets of this device, connect the sets and, if necessary, install some barriers such that mutual interference does not occur. For details, refer to " **PREVENTING MUTUAL INTERFERENCE BY DEVICE PLACEMENT**".
 - The corresponding emitter and receiver must have the same serial No. and be correctly oriented.

- Machine in which this device is installed**
 - When this device is used in "PSDI mode", an appropriate control circuit must be configured between this device and the machine. For details, be sure to refer to the standards and regulations applicable in each region or country.
 - Do not install this device with a machine whose operation cannot be stopped immediately in the middle of an operation cycle by an emergency stop equipment.
 - This device starts the performance after 2 seconds from the power ON. Have the control system started to function with this timing.

- Wiring**
 - Be sure to carry out the wiring in the power supply OFF condition.
 - All electrical wiring should conform to the regional electrical regulations and laws.
 - The wiring should be done by engineer(s) having the special electrical knowledge.
 - Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.
 - In case of extending the cable of the emitter or the receiver, each can be extended up to 70m by using the exclusive cable (Total length 10.5m or less when source/sink current is 350mA.). To use in a series connection, refer to the manual on our website.
 - Do not apply stress such as excessive bending or pulling to a cable or the extracted part of a cable. In particular, the material becomes hard at low temperature and soft at high temperature, and thus caution is required as bending or pulling with excessive force may cause wires to break.
 - Do not control the device only at one control output (OSSD 1 / 2).
 - In order that the output is not turned to ON due to earth fault of the control output (OSSD 1 / 2) wires, be sure to ground to 0V side (PNP output) / +V side (NPN output).
 - When using this device in Korea with KCs-mark, be sure to ground to 0V side (PNP output). (Applicable model: SF4D--)

- Maintenance**
 - When replacement parts are required, always use only genuine supplied replacement parts. If substitute parts from another manufacturer are used, the device may not come to detect, result in death or serious injury.
 - The periodical inspection of this device must be performed by an engineer having the special knowledge.
 - After maintenance or adjustment, and before starting operation, test this device following the procedure specified in " **MAINTENANCE**".
 - Clean this device with a clean cloth. Do not use any volatile chemicals.

- Others**
 - Never modify this device. Modification may cause the device not to detect objects, resulting in death or serious injury.
 - Do not use this device to detect objects flying over the detection area.
 - Do not use this device to detect transparent objects, translucent objects or objects smaller than the specified minimum object to be detected.

2 APPLICABLE STANDARDS / REGULATIONS

- <EU Directives>**
 - EU Machinery Directive 2006/42/EC
 - EMC Directive 2014/30/EU
- <British Legislation>**
 - Machinery Regulations 2008/1597
 - EMC Regulations 2016/1091
- Applicable Standards**
 - EN ISO 13849-1: 2015 (Category 4, PL e), EN 55011, EN 61000-6-2, IEC 61496-1/2 (Type 4), IEC 61508-1 to 3 (SIL3)
- <International Standards>**
 - IEC 61496-1 (Type 4), IEC 61496-2 (Type 4)
 - ISO 13849-1: 2015 (Category 4, PL e), IEC 61508-1 to 3 (SIL3)
- <Japanese Industrial Standards (JIS)>**
 - JIS B 9704-1/2 (Type 4), JIS B 9705-1 (Category 4), JIS C 0508-1 to 3 (SIL3)
- <Standards in US / Canada>**
 - ANSI/UL 61496-1/2 (Type 4)
 - CAN/CSA E61496-1/2
- <Regulations in US>**
 - OSHA 1910.212, OSHA 1910.217 (C), ANSI B11.1 to B11.19, ANSI/RIA 15.06
- <Japanese Regulations>** (Applicable model: SF4D--01)
 - Standards for safety device mechanisms for press machines and shearing machines.
 - <Standards in China>**
 - GB/T 4584
 - <Standards in Korea>** (Applicable model: SF4D--01)
 - Korea with KCs-mark

For Machinery Directive, type certification a Notified Body TÜV SÜD has been acquired. For the standards in US / Canada, cTÜVus mark by a Notified Body TÜV SÜD has been acquired.

When using as a safety device for a press machine or paper shearing machine in Japan (Applicable model: SF4D--01)

In Japan, this device can only be used as a safety device for press machines and paper shearing machines that meet the specifications below.

<Press machines>	
Item	Specifications
Machine type	Press machine with an emergency stop mechanism and restart prevention mechanism
Pressure capacity	50,000N or less
Emergency stop time	500ms or less
Stroke length	(Protection height - Die height) or less
Mold size range	Bolster width or less

<Shearing machine>	
Item	Specifications
Machine type	Shearing machine with an emergency stop mechanism and restart prevention mechanism
Shearing thickness	200mm or less
Shearing width	5,000mm or less
Blade length	5,500mm or less

<Japanese regulations>
Standards for safety device mechanisms for press machines and shearing machines. This device has passed, as indicated below, the "Type Examination" based on Article 44, 2 of the Industrial Safety and Health Law of Japan.

When using as a safety device for a press machine or paper shearing machine in Japan, always attach the protective tube **SFPD-A10** (option) to the cable. The safety device cannot be used for a press machine or shearing machine unless a protective tube is attached to the cable.


<Type Examination Numbers>			
Model No.	Type Examination Number	Press machine	Shearing machine
SF4D-F--01, SF4D-H--01	TA685	TA685	TA685
SF4D-A--01	TA684	TA684	TA682
SF4D-F--01, SF4D-H--01	SF-C11	TA687	—
SF4D-A--01	SF-C11	TA688	—
SF4D-F--01, SF4D-H--01	SF-C13	TA689	—
SF4D-A--01	SF-C13	TA688	—

- Type Examination Numbers TA685 (press machine) and TA683 (shearing machine) are indicated on SF4D-F--01 units and SF4D-H--01 units, and Type Examination Numbers TA684 (press machine) and TA682 (shearing machine) are indicated on SF4D-A--01 units.
- When only this device is used, or when this device is used in combination with the specified control unit, a different Type Examination Number applies. When used in combination with the specified control unit, the Type Examination Number is indicated on the control unit.
- When used in combination with the specified control unit, this device cannot be used for a shearing machine.

3 CONFIRMATION OF PACKED OBJECTS

- Main body: emitter and receiver One for each
- Test Rod 1 piece
- SF4D-F--01, SF4B-TR14 (ø14 × 220mm) 1 piece
- SF4D-H--01, SF4B-TR25 (ø25 × 220mm) 1 pc. for each language
- Quick Instruction Manual: Japanese, English, Chinese, Korean (excludes the SF4D--01) 1 pc. for each language
- General Information for Safety, Compliance, and Instructions 1 pc.

4 NAMES AND FUNCTIONS OF INDICATORS



• Emitter / receiver common	
Name	Function
Upper application indicator (Blue / Red / Green / Orange)	<When beam axis alignment mode is set> Control output (OSSD 1 / 2) ON: Lights blue. When top end beam channel receives light: Lights red. When top end beam channel is blocked: Turns OFF
Lower application indicator (Blue / Red / Green / Orange)	<When beam axis alignment mode is set> Control output (OSSD 1 / 2) ON: Lights blue. When bottom end beam channel receives light: Lights red. When bottom end beam channel is blocked: Turns OFF
Stable light reception indicator (Green / Orange)	When light reception is stable: Lights green When light reception is unstable: Lights orange When light is blocked: Turns OFF
Digital indicator (Green / Yellow)	Received light intensity (Green) Light intensity / Level 3: Lights green "3" Light intensity / Level 2: Lights green "2" Light intensity / Level 1: Lights green "1" When light is blocked: Turns OFF
Frequency indicator (Orange)	Normal operation: Turns OFF. Error: Number blinks or lights yellow "0" When PNP output is set: Lights yellow "0" (only during startup) When NPN output is set: Lights yellow "n" (only during startup)
	When frequency 1 is set: One indicator lights orange When frequency 2 is set: Two indicators light orange

• Emitter	
Name	Function
Light emission intensity control indicator (Orange)	Short mode: Turns OFF. Long mode: Lights orange
Test indicator (Orange)	During test: Lights orange. Normal operation: Turns OFF
Operation indicator (Red / Green)	Control output (OSSD 1 / 2) OFF: Lights red Normal operation: Lights green Control output (OSSD 1 / 2) ON: Lights green Error: Lights red

• Receiver	
Name	Function
Function setting indicator (Orange)	Communication mode connected: Blinks orange Blanking function or parallel connection used: Lights orange (Applicable model: SF4D--01) (Note)
Interlock indicator (Yellow)	Interlock activated: Lights yellow. All other times: Turns OFF
OSSD indicator (Red / Green)	Control output (OSSD 1 / 2) OFF: Lights red Control output (OSSD 1 / 2) ON: Lights green

Note: For details on the blanking function and parallel connection, refer to "SF4D Series Instruction Manual".

5 DIP SWITCH SETTINGS

For detailed information on the functions of the device, refer "our web site: <https://industry.panasonic.com/>".


- DIP Switch Settings**
- <Changing settings using the DIP switches>**

Item	Description	Settings and ranges, indicator	Factory default setting
DIP switch 1 / 2 (Emitter / Receiver) Synchronization method	Selects the synchronization method. When optical synchronization is selected, you can set a different frequency to reduce mutual interference.	Line synchronization • DIP switch 1: OFF • DIP switch 2: OFF Frequency indicator (orange): Turns OFF Optical synchronization, Frequency 1 • DIP switch 1: ON • DIP switch 2: OFF Frequency indicator (orange): One indicator lights Optical synchronization, Frequency 2 • DIP switch 1: OFF • DIP switch 2: ON Frequency indicator (orange): Two indicators light	Line synchronization
DIP switch 3 (Emitter) Light emission intensity control function	Controls the light from the emitter for the change of sensing range.	Short mode Sensing range SF4D-F--(01): 0.2 to 7m SF4D-H--(01), SF4D-A--(01): 0.2 to 9m • DIP switch 3: OFF Light emission intensity control indicator (orange): Turns OFF Long mode Sensing range SF4D-F--(01): 0.8 to 12m SF4D-H--(01), SF4D-A--(01): 0.8 to 15m • DIP switch 3: ON Light emission intensity control indicator (orange): Turns ON	Short mode
DIP switch 3 (Receiver) Indicator selector	The upper application indicator and lower application indicator can be used as a beam axis alignment mode or an application mode.	Beam axis alignment mode • DIP switch 3: ON Application mode • DIP switch 3: OFF	Beam axis alignment mode
DIP switch 4 (Emitter / Receiver) Power save mode	Turns OFF the indicators reduce power consumption.	Normal mode (Allows illumination of some indicators) • DIP switch 4: OFF Power save mode (Upper application indicator and lower application indicator, digital indicator / received light intensity are always turns OFF) • DIP switch 4: ON	Normal mode

CAUTION

Make sure that the power is OFF when setting DIP switch 1 / 2 (emitter / receiver) and DIP switch 3 (emitter). If DIP switch settings are changed while the power is ON, the settings will not be reflected. The settings will be reflected after the power is turned OFF and then turned back ON.

- Remove the indicator cover from the device to access the DIP switches.



CAUTION

- After setting the DIP switches, always reattach the indicator cover on the device. Tighten to a torque of 0.3N·m or less.
- There is packing on the indicator cover. If the packing is not fitted on the cover properly, fit as shown below before attaching to the device.



6 PREVENTING MUTUAL INTERFERENCE BY DEVICE PLACEMENT

- This section describes methods for placing 2 or more sets of emitters and receivers facing each other, rather than in a series or parallel connection. Consider these when there is a wiring problem or you need to test the system in conjunction with changes such as adding new equipment. Use a test rod to perform an operation test.

WARNING

- Refer to and understand the examples of device placement given below before installing the devices. Risk of death or serious injury if the devices are not placed correctly.
- When using multiple sets of the device, install so as to avoid mutual interference. Risk of death or serious injury if mutual interference occurs.

<Examples of device placement>

1) Side-by-side placement



2) Vertical placement



3) Front and back placement



4) With a light-blocking barrier




<Reference>

If you have questions or problems, please contact our office.

WARNING

The emitter and receiver cables must be oriented in the same direction. Risk of malfunctioning if the cables are not in the same oriented in the same direction.



7 MOUNTING

CAUTION

- The minimum bending radius of the cables is R6mm. Keep the minimum bending radius of the cables in mind during installation.
- Do not apply stress such as excessive bending or pulling to the extracted part of a cable.
- After installing this device, be sure to adjust the beams so that the device's stable light reception indicator lights green and the number "3" lights green on the digital indicator. To adjust the beams, refer to the manual on our website.

When using as a safety device for a press machine or paper shearing machine in Japan (Applicable model: SF4D--01)


- When using as a safety device for a press machine or paper shearing machine in Japan, always attach the protective tube **SFPD-A10** (option) to the cable.
- The minimum bending radius of the cable with the protective tube **SFPD-A10** attached is 55mm. Take into consideration the minimum bending radius of the cable with the protective tube **SFPD-A10** attached.

<Reference>


Mount the emitter and the receiver at the same level and parallel to each other. The effective aperture angle of the device is ±2.5° or less for a sensing range of 3m.

<Using beam adjustment mounting bracket MS-SFD-1-5 (Option)>

- Insert the mounting plate of the base bracket into the base bracket mounting rail on the back of the device.




- With the base bracket in firm contact with the device, tighten the two ultra low-head hex socket bolts [M5 (length 5mm), opposing faces 3mm] that fasten the base bracket. Tighten to a torque of 3N·m or less.




<Side mounting>

- Loosen the two hexagon-socket head bolts with washers [M4 (length 8mm), opposing faces 3mm] and remove the bracket.
- Change the orientation of the mounting bracket, and tighten the two hexagon-socket head bolts with washers [M4 (length 8mm), opposing faces 3mm]. Tighten to a torque of 1.5N·m or less.




- Install the beam adjustment mounting bracket on the mounting surface with a hexagon-socket head bolt (purchase separately).




<Using intermediate supporting bracket MS-SFB-2 (Option)>

- Loosen the hexagon-socket head bolt [M4 (length 12mm), opposing faces 3mm] on the intermediate supporting bracket.




- Fit the intermediate supporting bracket onto the side of the device, and fasten with the hexagon-socket head bolt [M4 (length 12mm), opposing faces 3mm]. Tighten to a torque of 1.2N·m or less.




<Slide mounting>

- Slide and remove the fixing fitting of the intermediate supporting bracket from the base bracket. Change the direction of the fixing fitting, and engage the notches on the fixing fitting with the rails on the base bracket.



- Install the intermediate supporting bracket on the mounting surface with two hexagon-socket head bolts [M5 (purchase separately)].



Note: When the number of beam axes is SF4D-F--: 111 or more beam axes, SF4D-H--: 56 or more beam axes, SF4D-A--: 28 or more beam axes, one set is required.

CAUTION

The intermediate supporting bracket **MS-SFB-2** is not intended to secure the device.


<Installing the bottom cap cables (Option)>

CAUTION


- Take care not to misplace any screws while you are working.
- The bottom cap cables are distinguished by round connector color. Gray is for the emitter, and black is for the receiver. Make sure that the correct cable is connected to the emitter and to the receiver.
- There is packing on the connector of the bottom cap cable. If the packing is not fitted on the connector properly, fit as shown below before connecting to the device.



- Insert the connector of the bottom cap cable (option) into the connector on the device. When inserting the connector, fit the cable into the groove on the device.



- Tighten the two M2.6 screws. Tighten to a torque of 0.3N·m or less.



8 WIRING

WARNING

- Ground the machine or support on which the device is installed to frame ground (F.G.). If not grounded properly, there is a risk of death or serious injury from malfunctioning caused by noise. Enclose the wiring in a metal wiring box connected to frame ground (F.G.).
- Design the system that uses the device so that dangerous operation will not be caused by a grounding failure. Risk of death or serious injury if the system cannot be stopped.
- If you are extending the synchronization + wire (orange) and synchronization - wire (orange / black) using a cable other than the special-use cable, use 0.2mm² or more twisted-pair cable, and extend 0V as well.
- For other than synchronization + wire (orange) and synchronization - wire (orange / black), use 0.3mm² or more cable.
- In the case of line synchronization, emitter and receiver 0V should be common.
- Always verify that nobody is in the danger zone before using the interlock function. Risk of death or serious injury.
- Install the reset switch in a location that allows operation from outside the danger zone and which provides

