



# 1598, 5088

## SIA PROTOCOL IN WEB-SERVER

Fire alarm solutions  
technical description

# Table of Contents

<b>1.</b>	<b>INTRODUCTION</b>	3
1.1.	REFERENCE DOCUMENTS	3
<b>2.</b>	<b>ABBREVIATIONS</b>	4
<b>3.</b>	<b>GENERAL DESCRIPTION</b>	5
<b>4.</b>	<b>PARAMETER CODES</b>	6
4.1.	DEFINITION	6
<b>5.</b>	<b>ALARM MESSAGES</b>	8
5.1.	ALARMS	8
5.2.	RESET OF ALARMS	16
<b>6.</b>	<b>FAULT MESSAGE</b>	17
6.1.	SYSTEM FAULTS	17
6.2.	CONTROL FAULTS	17
6.3.	EXPANSION BOARD FAULTS	21
6.4.	LOOP FAULTS	23
6.5.	LOOP UNIT FAULTS	25
6.6.	OTHER FAULTS	30
<b>7.</b>	<b>DISABLEMENT MESSAGES</b>	33
<b>8.</b>	<b>SERVICE SIGNAL MESSAGES</b>	37
<b>9.</b>	<b>MISCELLANEOUS MESSAGES</b>	38
<b>10.</b>	<b>COMPATIBILITY TABLE</b>	44
<b>11.</b>	<b>TECHNICAL DATA</b>	44

# 1. INTRODUCTION

This document describes the subset of the SIA messages that is implemented in protocol version II for Web-server 1598 and Gateway 5088.

The SIA protocol covers not only fire alarm messages, but also burglary alarm messages, medical equipment alarm messages etcetera.

## 1.1. REFERENCE DOCUMENTS

- [1] Security Communications – Digital Communications Standard – “SIA Format” Protocol – for Alarm System Communications (SIA DC-03-1990.01(R2003.10))


## 2. ABBREVIATIONS

<b>CIE / CU</b>	Control and indicating equipment	= control unit
<b>LADR</b>	(L=Loop, ADR = NMAST address)	
<b>The application</b>	The application in the webserver	
<b>Webserver</b>	Webserver II 1598 or Gateway 5088	

### 3. GENERAL DESCRIPTION

If configured for the SIA protocol, the Web-server 1598 / Gateway 5088 will send messages according to this document on the modem comport.

At the same time Web-server 1598 / Gateway 5088 can act as the usual webserver application, allowing users to browse for fire alarms and so on.



## 4. PARAMETER CODES

### 4.1. DEFINITION

Code	Parameter	Size (byte)	
STATUS	Generic status byte. Can for example be fault status (fault activated, fault deactivated or fault acknowledged) or door status (opened/closed).	1	Context dependent.
DATA	Generic sequence of bytes. The meaning is specified in those section that use it.	N/A	Context dependent.
CU	Control Unit Number	1	0..29
YEAR	Year	1	00..99
MONTH	Month	1	1..12
DATE	Date	1	1..31
HOUR	Hour	1	0..23
MIN	Minute	1	0..59
RST	Restart code	1	0..255
MEM	Memory address	4	0.. 4294967295
EXPBOARD	8 zones expansion board 1580 = 0, 8 relays expansion board 1581 = 1, External fire brigade panel interface board 1582 = 2, German external fire brigade panel interface board 1583 = 3, Autronica interface board 1584 = 4, External FBP/DU interface board 1587 = 5	1	0..5
BOARDNO	Expansion board address	1	0..7
OUTNO <sup>1</sup>	Output number	1	0..7
LOOPNO	Loop number / Zone line number	1	0..7
SCINO	SCI number	1	0..8
TECHNO	Technical number	3	
FBPNO	Fire brigade panel number	1	0..7
AREA	Interlocking area	2	1..999
POINT	Interlocking point	1	1..99
ZONE		2	
ADDRESS		1	1..99
ALARMTXT	A string of printable characters	40	

1) There are three places where an output can be placed; On a control unit, on an expansionboard and on a loop unit. For the two latter OUTNO is just an enumeration, but for a control unit we distinguish between the relay outputs and the supervised outputs. In this case we set OUTNO to 0 and 1 for R0 and R1, and we set OUTNO to 2..5 for S0..S3.

Code	Parameter	Size (byte)	
REASON	"No Reason", "Manual", "TimeChannel", "OpenDoor", "CloseDoor", "Interlocking", "GlobalManual" or "KeyPressed"		
DEVICETYPE	Control = 0, ventilation = 1, extinguisher = 2, alarm devices = 3, ATR = 4, FTR = 5, interlocking = 6	1	0..6
BOOL	0 = false, 1 = true	1	0..1
LOOPUNITTYPE	Type of loop unit. One of Smoke sensor Heat detector Multi detector Manual call point Other		
ALGO	Currently the system have 24 different algorithms.	1	0..23

In the following sections a description of the SIA activating string is written in the comments sections. In most cases the SIA reset string look exactly the same except for the two letter SIA codes, and has not been written there. In those cases where the SIA reset string differs in more than the SIA codes it is also shown in the comments section.

## 5. ALARM MESSAGES

### 5.1. ALARMS

The Web-server / Gateway will send notifications about an alarm points change of state, for example from normal state to fire state. Only the new state will be specified though.

*Note that not all alarms are connected to a loop unit, that is, not all alarms can be associated with a TECHNO.*

Message <b>Pre Warning (smoke)</b>	SIA Activate FS	SIA reset FV
Parameters Area    ZONE Address ADDRESS PI      TECHNO Text    ALARMTXT		
Description		
Comments piTECHNO / riZONE / FSADDR*sss...s*		

Message <b>Pre Warning (heat)</b>	SIA Activate DP	SIA reset FV
Parameters Area    ZONE Address ADDRESS PI      TECHNO Text    ALARMTXT		
Description		
Comments piTECHNO / riZONE / DPADDR*sss...s*		



Message <b>Pre Warning (multi)</b>	SIA Activate DQ	SIA reset FV
Parameters Area ZONE Address ADDRESS PI TECHNO Text ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DQ <b>ADDR*sss...s*</b>		

Message <b>Pre Warning (other)</b>	SIA Activate CK	SIA reset FV
Parameters Area ZONE Address ADDRESS PI TECHNO Text ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / CK <b>ADDR*sss...s*</b>		

Message <b>Alarm (smoke)</b>	SIA Activate UA	SIA reset FH
Parameters Area ZONE Address ADDRESS PI TECHNO Text ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DA <b>ADDR*sss...s*</b>		

Message <b>Alarm (heat)</b>	SIA Activate KA	SIA reset KH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / KA <b>ADDR*sss...s*</b>		

Message <b>Alarm (multi)</b>	SIA Activate DM	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DB <b>ADDR*sss...s*</b>		

Message <b>Alarm (manual call point)</b>	SIA Activate DD	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DD <b>ADDR*sss...s*</b>		

Message <b>Alarm (other)</b>	SIA Activate FA	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / FAADDR* <b>sss...s</b> *		

Message <b>Heavy Smoke Alarm (smoke)</b>	SIA Activate DE	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DEADDR* <b>sss...s</b> *		

Message <b>Heavy Heat Alarm (heat)</b>	SIA Activate DF	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DFADDR* <b>sss...s</b> *		

Message <b>Heavy Smoke Alarm (multi)</b>	SIA Activate DS	SIA reset FH
Parameters Area ZONE Address ADDRESS PI TECHNO Text ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DSADDR* <b>sss...s</b> *		

Message <b>Heavy Heat Alarm (multi)</b>	SIA Activate OC	SIA reset FH
Parameters Area ZONE Address ADDRESS PI TECHNO Text ALARMTXT		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / OCADDR* <b>sss...s</b> *		

Message <b>2 Detector Dependant Alarm</b>	SIA Activate FG	SIA reset FV
Parameters Area ZONE Address ADDRESS PI TECHNO Text TYPEOFLOOPUNIT, ALARMTXT		
Description An alarmpoint that is configured for two detector dependency or two zone dependency will enter this state instead of the alarm state.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / FGADDR* <b>sss...s</b> *		

Message <b>Alert Annunciation Alarm (smoke)</b>	SIA Activate GA	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description An alarmpoint configured for alert annunciation will enter this state instead of the alarm state, but only if there are no alarmpoints already in the alarm state.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / GA <b>ADDR*sss...s*</b>		

Message <b>Alert Annunciation Alarm (heat)</b>	SIA Activate DV	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description An alarmpoint configured for alert annunciation will enter this state instead of the alarm state, but only if there are no alarmpoints already in the alarm state.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DV <b>ADDR*sss...s*</b>		

Message <b>Alert Annunciation Alarm (multi)</b>	SIA Activate DW	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description An alarmpoint configured for alert annunciation will enter this state instead of the alarm state, but only if there are no alarmpoints already in the alarm state.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DW <b>ADDR*sss...s*</b>		

Message <b>Alert Annunciation Alarm (MCP)</b>	SIA Activate DX	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description An alarmpoint configured for alert annunciation will enter this state instead of the alarm state, but only if there are no alarmpoints already in the alarm state.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DXADDR* <b>sss...s</b> *		

Message <b>Alert Annunciation Alarm (other)</b>	SIA Activate DZ	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    ALARMTXT		
Description An alarmpoint configured for alert annunciation will enter this state instead of the alarm state, but only if there are no alarmpoints already in the alarm state.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / DZADDR* <b>sss...s</b> *		

Message <b>Alert Annunciation Acknowledged</b>	SIA Activate GH	SIA reset FH
Parameters Area    ZONE Address ADDRESS PI     TECHNO Text    TYPEOFLOOPUNIT, ALARMTXT		
Description The alert annunciated alarm has been acknowledged		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / GHADDR* <b>sss...s</b> *		

Message <b>Alarm In Test Mode</b>	SIA Activate FX	SIA reset FV
Parameters Area ZONE Address ADDRESS PI TECHNO Text TYPEOFLOOPUNIT, ALARMTXT		
Description A zone has been placed in test mode and an alarm point in the zone (or the entire zone) has detected fire. No outputs are activated. After 10 seconds the alarmpoint (zone) will enter normal state.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / FXADDR* <b>sss...s</b> *		

Message <b>Alarm State By Menu</b>	SIA Activate FA	SIA reset FH
Parameters Area ZONE Address ADDRESS PI TECHNO Text TYPEOFLOOPUNIT, ALARMTXT		
Description A zone has been placed in test mode and an alarm point in the zone (or the entire zone) has detected fire. No outputs are activated. After 10 seconds the alarmpoint (zone) will enter normal state.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / FAADDR* <b>sss...s</b> *		

## 5.2. RESET OF ALARMS

Message <b>Encapsulated Reset</b>	SIA Activate KS	SIA reset
Parameters Area    ZONE Address  ADDRESS PI      TECHNO Text		
Description All individual alarm has been reset with encapsulation.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / BDADDR* <b>sss...s</b> *		



## 6. FAULT MESSAGE

### 6.1. SYSTEM FAULTS

Message <b>System Communication Fault</b>	SIA Activate DC	SIA reset DG
Parameters Area Address CU1 PI CU2 Text		
Description CU1 has no contact with CU2		
Comments piCU0000 / DC00CU piCU0000 / DC00AA Communication error between Web and EBL		

### 6.2. CONTROL FAULTS

Message <b>No Battery Connected</b>	SIA Activate YM	SIA reset YR
Parameters Area Address PI CU Text		
Description		
Comments piCU0000 / YM0000		

Message <b>Low System Voltage</b>	SIA Activate YT	SIA reset YR
Parameters Area Address PI CU Text		
Description		
Comments piCU0000 / YT0000		

Message <b>Main Power Supply Fault</b>	SIA Activate AT	SIA reset AR
Parameters Area Address    See comment PI    CU Text		
Description		
Comments 10 = Control unit 20 = External mains fault piCU0000 / AT0010 piCU0000 / AT0020		

Message <b>Other Power Supply Fault</b>	SIA Activate YP	SIA reset YQ
Parameters Area Address    See comment PI    CU Text		
Description		
Comments 10 = earth fault (plus) 20 = earth fault (minus) 30 = Low battery capacity 40 = Low main power supply voltage 50 = Fault on external power supply 60 = External charge fault 70 = Fault on power supply for routing Equipment 80 = Fault On Power Supply For External Equipment piCU0000 / YP0010 ... piCU0000 / YP0080		

Message <b>Fault On External Fuses</b>	SIA Activate NA	SIA reset NS
Parameters Area Address PI CU Text		
Description		
Comments piCU0000 / NA0010		

Message <b>Restart Fault</b>	SIA Activate HT	SIA reset
Parameters Area Address RESTARTCODE PI CU Text MEMORYADDRESS		
Description		
Comments No SIA reset code piCU0000 / YWCODE*MEMORYADDRESS*		

Message <b>General Data Error</b>	SIA Activate IA	SIA reset IR
Parameters Area Address See comment PI CU Text		
Description		
Comments 10 = SSD fault 20 = SSW fault 30 = SSI fault 40 = wrong information fault 50 = program area fault piCU0000 / IA0010 ... piCU0000 / IA0050		

Message <b>TLON Board Fault</b>	SIA Activate NC	SIA reset CR
Parameters Area Address PI CU Text		
Description		
Comments pi <b>CU</b> 0000 / NC0000		

Message <b>High Current Consumption Fault</b>	SIA Activate YI	SIA reset YJ
Parameters Area Address PI CU Text		
Description		
Comments pi <b>CU</b> 0000 / YI0000		

Message <b>Incompatible Software Version</b>	SIA Activate CO	SIA reset
Parameters Area Address PI CU Text CUVERSION, WEBVERSION		
Description Control unit and Web server software version not compatible		
Comments pi <b>CU</b> 0000 / CO0000*CU= <b>VERSION</b> , WEB= <b>VERSION</b> *		

### 6.3. EXPANSION BOARD FAULTS

Message <b>General Expansion Bord Fault</b>	SIA Activate ET	SIA reset ER
Parameters Area Address BOARDNO PI CU Text		
Description Fault on / no communication to an expansion board.		
Comments DET8 board: pi <b>CU0000</b> / ET000B RE8 board: pi <b>CU0000</b> / ET001B FBP board: pi <b>CU0000</b> / ET002B GFBP board: pi <b>CU0000</b> / ET003B BS4 board: pi <b>CU0000</b> / ET004B DU board: pi <b>CU0000</b> / ET005B		

Message <b>Fault On Extinguishing System On Expansion Board</b>	SIA Activate ST	SIA reset SR
Parameters Area Address BOARDNO (BB) PI CU Text		
Description Fault in the extinguishing system / equipment connected to a 1583 expansion board.		
Comments pi <b>CU0000</b> / ST00BB		

Message <b>Fault On Wire To Extinguishing System On Expansion Board</b>	SIA Activate SS	SIA reset SJ
Parameters Area Address BOARDNO PI CU Text		
Description Short circuit / cut-off on the wires from a 1583 expansion board to the connected extinguishing system / equipment.		
Comments pi <b>CU0000</b> / SS00BB		

Message <b>High Voltage On Expansion Board</b>	SIA Activate LT	SIA reset LR
Parameters Area Address    BOARDNO PI        CU Text		
Description One or more loops on the BS4 expansion board has a voltage > 16V		
Comments pi <b>CU0000</b> / LT <b>00BB</b>		

## 6.4. LOOP FAULTS

Message <b>Open Circuit Fault On Loop</b>	SIA Activate MA	SIA reset MH
Parameters Area Address LBSS (see comment) PI CU Text		
Description This is indicating a single break on a loop.		
Comments piCU0000 / MAL000 (NMAST loop) piCU0000 / MALASS (NMAST loop, between SCIs 'SS') piCU0000 / MALB0A (Autronica loop)		

Message <b>Open Circuit Fault On Conventional Zone Line</b>	SIA Activate HA	SIA reset HH
Parameters Area ZONE Address ADDRESS PI CU Text BOARDNO, LOOPNO		
Description This is indicating a break on the conventional zone line.		
Comments piCU0000 / ri0000 / HA0000*BOARDNO:B LOOPNO:L*		

Message <b>Short Circuit Fault On Loop</b>	SIA Activate ZA	SIA reset ZH
Parameters Area Address LBSS (see comment) PI CU Text		
Description Short circuit on a loop		
Comments piCU0000/ZAL000 (NMAST loop) piCU0000/ZALASS (NMAST loop, between SCIs 'SS') piCU0000/ZALB0A (Autronica loop)		

Message <b>Short Circuit Fault On Conventional Zone Line</b>	SIA Activate FT	SIA reset FR
Parameters Area     ZONE Address ADDRESS PI     CU Text    BOARDNO, LOOPNO		
Description Short circuit on a zone line.		
Comments piCU0000 / riZONE / FTADDR*BOARDNO:B LOOPNO:L*		

Message <b>L And C Mixed On Loop</b>	SIA Activate QA	SIA reset QH
Parameters Area Address LOOPNO PI     CU Text		
Description The two wires L (SA) and C (SB) have been mixed (alternated).		
Comments piCU0000/QA00LL		

Message <b>High Current Consumption On Autronica Loop</b>	SIA Activate PA	SIA reset PH
Parameters Area Address BOARDNO , LOOPNO PI     CU Text		
Description The current consumption is > 60 mA on the BS4 loop.		
Comments piCU0000 / PA00BL		



## 6.5. LOOP UNIT FAULTS

For those loop units that hold an alarm point or a zone, the zone-address or zone is included in the fault message.

Message <b>General Loop Unit Fault</b>	SIA Activate FW	SIA reset FJ
Parameters Area    ZONE Address ADDRESS PI    TECHNO Text		
Description		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / FWADDR		

Message <b>No Reply From Loop Unit</b>	SIA Activate FY	SIA reset DK
Parameters Area    ZONE Address ADDRESS PI    TECHNO Text		
Description No communication with the loop unit.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / FYADDR		

Message <b>Wrong Type Of Loop Unit</b>	SIA Activate TA	SIA reset TR
Parameters Area    ZONE Address ADDRESS PI    TECHNO Text		
Description The unit is not the same type as programmed.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / TAADDR		

Message <b>Loop Unit Fuse Fault</b>	SIA Activate DI	SIA reset DJ
Parameters Area Address LADR PI TECHNO Text		
Description Fuse F9 (on the output unit p.c.b.) is blown.		
Comments pi <b>TECHNO</b> / DILADR		

Message <b>Loop Unit Battery Fault</b>	SIA Activate WA	SIA reset WR
Parameters Area Address LADR PI TECHNO Text		
Description Fault on battery or connections for battery in external power supply.		
Comments pi <b>TECHNO</b> / WALADR		

Message <b>Loop Unit Mains Fault</b>	SIA Activate EA	SIA reset JH
Parameters Area Address LADR PI TECHNO Text		
Description No main power to the loop unit.		
Comments pi <b>TECHNO</b> / EALADR		

Message <b>Loop Unit Earth Fault</b>	SIA Activate EE	SIA reset JK
Parameters Area Address LADR PI TECHNO Text		
Description Earth fault in output unit.		
Comments pi <b>TECHNO</b> / EELADR		

Message <b>Loop Unit 2235 Id Fault</b>	SIA Activate JL	SIA reset JO
Parameters Area Address LADR PI TECHNO Text		
Description The display unit is not the same type as programmed.		
Comments pi <b>TECHNO</b> / JLLADR		

Message <b>Loop Unit Double Address Fault</b>	SIA Activate JP	SIA reset JS
Parameters Area ZONE Address ADDRESS PI TECHNO Text		
Description Two or more loop units connected to a BS4 loop have been given the same address.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / JPADDR		

Message <b>Loop Unit Charge Fault</b>	SIA Activate BS	SIA reset BJ
Parameters Area Address LADR PI TECHNO Text		
Description Charging function in external power supply doesn't work properly.		
Comments pi <b>TECHNO</b> / BSLADR		

Message <b>Loop Unit Power Out Fault</b>	SIA Activate BT	SIA reset BR
Parameters Area Address LADR PI TECHNO Text		
Description The output current is > 4A. (The output might also be turned off.)		
Comments pi <b>TECHNO</b> / BTLADR		

Message <b>Loop Unit Low Voltage Fault</b>	SIA Activate GS	SIA reset GJ
Parameters Area Address LADR PI TECHNO Text		
Description The external power supply's system voltage < 21 V DC.		
Comments pi <b>TECHNO</b> / GSLADR		

Message <b>Loop Unit Zone Line Input Fault</b>	SIA Activate UZ	SIA reset UJ
Parameters Area     ZONE Address   ADDRESS PI        TECHNO Text		
Description Detector mounted in an ADB 2330: faulty / removed detector or Ext. line (input) to an ADB 2330: break on a wire or wrong / no end-of-line resistor or Zone interface 2335 / 2226 (input): break on a wire or wrong / no end of line resistor.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / BZ <b>ADDR</b>		

## 6.6. OTHER FAULTS

Message <b>Monitored Output Fault</b>	SIA Activate UG	SIA reset OV
Parameters Area Address   OUTNO PI    CU Text		
Description Not calibrated or fault on monitored output		
Comments pi <b>CU0000</b> / <b>OUOUTN</b>		

Message <b>Monitored Loopunit Output Fault</b>	SIA Activate UG	SIA reset OV
Parameters Area    OUTNO Address LADR PI    TECHNO Text		
Description Not calibrated or fault on monitored output on loop unit		
Comments pi <b>TECHNO</b> / ri <b>0000</b> / <b>OULADR</b>		

Message <b>Interlocking Fault</b>	SIA Activate GT	SIA reset GR
Parameters Area    AREA Address POINT PI    CU Text		
Description An interlocking input is not activated within the time set for fault activation.		
Comments pi <b>CU0000</b> / ri <b>AREA</b> / <b>GTPOIN</b>		

Message <b>General Fuse Fault</b>	SIA Activate NA	SIA reset NS
Parameters Area Address PI CU Text		
Description Fuse(s) blown on expansion board, loops, or external fuses.		
Comments 0-9 = Loop 10 = External fuses 100-199 = Expansion board piCU0000 / NA0010 piCU0000 / NA012B (Fuse on FBP expansion board) piCU0000 / NA010B (Fuse on DET8 board) piCU0000 / NA014B (Fuse on BS4 board) piCU0000 / NA015B (Fuse on DU board)		

Message <b>Key Cabinet Fault</b>	SIA Activate BA	SIA reset BH
Parameters Area Address PI CU Text		
Description The key cabinet has been opened without a prior fire alarm.		
Comments piCU0000 / BA0000		

Message <b>External Fault</b>	SIA Activate EJ	SIA reset ES
Parameters Area Address PI CU Text TEXT		
Description A user defined fault message generated via programmable input		
Comments pi <b>CU</b> 0000 / EJ0000*... <b>TEXT</b> ...*		

Message <b>Fire Brigade Panel General Fault</b>	SIA Activate EM	SIA reset EN
Parameters Area Address BOARDNO, FBPN0 PI CU Text		
Description The control unit can not communicate with the ext. FBP (or data converter).		
Comments pi <b>CU</b> 0000 / EM00 <b>BF</b>		



## 7. DISABLEMENT MESSAGES

Message <b>Alarm point disabled</b>	SIA Activate FB	SIA reset FU
Parameters Area    ZONE Address ADDRESS PI    TECHNO Text    REASON, AUTOREENABLE, HOUR, MINUTE		
Description The alarm point ZONE-ADDRESS has been disabled. If AUTOREENABLE is equal to 1, the parameters HOUR and MINUTE tells when the alarmpoint will be automatically reenabled.		
Comments ADDR == AA means entire zone piTECHNO / riZONE / FBADDR*REASON:Local Manual, AUTOREENABLE: HH:MM* piTECHNO / riZONE / FBADDR*REASON:Local Manual* piTECHNO / riZONE / FBADDR*REASON:TimeChannel* piTECHNO / riZONE / FUADDR pi000000 / riZONE / FB00AA*REASON:Local Manual, AUTOREENABLE: HH:MM* pi000000 / riZONE / FU00AA		

Message <b>NMAST loop disabled</b>	SIA Activate HS	SIA reset HR
Parameters Area Address    LOOPNO PI    CU Text		
Description The loop LOOPNO on control unit CU has been disabled.		
Comments pi <b>CU</b> 0000 / HS000L		

Message <b>BS4 Loop Disabled</b>	SIA Activate MS	SIA reset MJ
Parameters Area Address BOARDNO, LOOPNO PI CU Text		
Description The loop LOOPNO on BS4 board BOARDNO on control unit CU has been disabled.		
Comments pi <b>CU0000</b> / MS00 <b>BL</b>		

Message <b>Zone line input on 1580 disabled</b>	SIA Activate PS	SIA reset PJ
Parameters Area ZONE Address ADDRESS PI CU Text BOARDNO, LOOPNO		
Description The loop LOOPNO on 1580 board BOARDNO on control unit CU has been disabled		
Comments pi <b>CU0000</b> /ri0000/PS0000*BOARDNO: <b>B</b> LOOPNO: <b>L</b> *		

Message <b>Zone line input on loop unit disabled</b>	SIA Activate QS	SIA reset QJ
Parameters Area ZONE Address ADDRESS PI TECHNO Text LOOPNO		
Description The zone line LOOPNO on loop unit with TECHNO has been disabled.		
Comments pi <b>TECHNO</b> / ri0000 / QS0000*LOOPNO: <b>L</b> *		

Message <b>Interlocking output disabled</b>	SIA Activate WS	SIA reset WJ
Parameters Area    AREA Address POINT PI Text		
Description The output on interlocking AREA-POINT has been disabled.		
Comments ri <b>AREA</b> / WS00PT		

Message <b>Output on control unit / expansionboard disabled</b>	SIA Activate ZS	SIA reset ZJ
Parameters Area Address BOARDNO, OUTNO, DEVICETYPE PI    CU Text		
Description An output on a control unit or expansion board has been disabled.		
Comments pi <b>CU0000</b> / ZS0 <b>TOD</b> *REASON: <b>RRR</b> * pi <b>CU0000</b> / ZS1 <b>BOD</b> *REASON: <b>RRR</b> * T = 0: Relay output on control unit (R0, R1) T = 1: Voltage output on control unit (S0 - S3) O: Output number D: Device type B: Expansion board number RRR: one of "No Reason", "Manual", "TimeChannel", "OpenDoor", "CloseDoor", "Interlocking", "GlobalManual" or "KeyPressed".		

Message <b>Output on a loop unit disabled</b>	SIA Activate AA	SIA reset AB
Parameters Area    OUTPUTNO Address PI    TECHNO Text		
Description Output OUTPUTNO on loop unit with technical number TECHNO has been disabled.		
Comments pi <b>TECHNO</b> / ri0000 / AALADR*REASON: <b>RRR</b> *		

Message <b>Device Type Disabled</b>	SIA Activate BV	SIA reset BX
Parameters Area Address    DEVICETYPE PI        CU Text      TYPETEXT		
Description All outputs of a certain device type has been disabled for a control unit, or in the whole system.		
Comments 0-9 = The control unit 10-19 = Globally pi <b>CU0000</b> / BV000 <b>D</b> *TYPE:TYPETEXT REASON: <b>RRR</b> * ( <b>RRR</b> as above). pi <b>CU0000</b> / BV001 <b>D</b> *TYPE:TYPETEXT REASON:Global Manual*		

## 8. SERVICE SIGNAL MESSAGES

Message <b>Service Signal</b>	SIA Activate AS	SIA reset AN
Parameters Area    ZONE Address ADDRESS PI    TECHNO Text		
Description A service signal from sensor with technical number TECHNO has been activated, deactivated or acknowledged.		
Comments pi <b>TECHNO</b> / ri <b>ZONE</b> / AS <b>ADDR</b>		

## 9. MISCELLANEOUS MESSAGES

Message <b>Test Mode Activated / De-activated</b>	SIA Activate FZ	SIA reset FK
Parameters Area    ZONE Address PI    CU Text		
Description		
Comments pi <b>CU</b> 0000 / ri <b>ZONE</b> / FI0000		

Message <b>Door Opened / Closed</b>	SIA Activate DN	SIA reset DH
Parameters Area Address    EBF PI    CU Text		
Description		
Comments AAA = CU 000 – 999 = Fire brigade panel pi <b>CU</b> 0000 / DN0AAA pi <b>CU</b> 0000 / DN0 <b>EBF</b>		

Message <b>Control Unit Shutdown</b>	SIA Activate KT	SIA reset KR
Parameters Area Address PI    CU Text		
Description		
Comments pi <b>CU</b> 0000 / CE0000		

Message <b>Silence Alarm Devices</b>	SIA Activate DT	SIA reset FQ
Parameters Area Address PI Text		
Description		
Comments FL0000		

Message <b>Downloading SSD Started</b>	SIA Activate LB	SIA reset
Parameters Area Address PI CU Text		
Description The download to control unit CU has begun.		
Comments piCU0000 / LB0000		

Message <b>Downloading SSD Completed</b>	SIA Activate LU	SIA reset LS
Parameters Area Address PI CU Text STATUS MESSAGE		
Description The download to control unit CU has completed.		
Comments piCU0000 / LU0000 (SSD checksum error after download) piCU0000 / LS0000 (Download ok)		

Message <b>Device Type Activated</b>	SIA Activate WF	SIA reset WH
Parameters Area    DEVICETYPE Address    N PI Text		
Description There are N outputs of device type DEVICETYPE currently activated.		
Comments riTYPE / CLNNNN riTYPE / CP0000		

Message <b>Login Attempts Exceeded</b>	SIA Activate JA	SIA reset
Parameters Area Address PI Text		
Description When a user has tried to log on to the webserver three times and failed, the webserver will send this message.		
Comments JA0000		

Message <b>Changed Password</b>	SIA Activate JV	SIA reset
Parameters Area Address PI Text    USERNAME		
Description		
Comments JV0000*USERNAME=N* 'N'is a one digit number. 0 = Daily user, 1 = Maintenance, 2 = Service, 3 = PC (Win512), 4 = Web user.		



Message <b>Automatic Fire Alarm Test</b>	SIA Activate RP	SIA reset
Parameters Area Address    VERSION PI Text		
Description		
Comments RP0VVV VERSION is the web server version on the form V.V.V. Example for version 1.0 of the webserver the SIA message is RP0100, for version 2.5.3 it's RP0253.		

Message <b>Extinguishing System Activated</b>	SIA Activate SA	SIA reset SH
Parameters Area Address PI Text		
Description This message is sent when 1 or more outputs of device type extinguishing system becomes activated.		
Comments SA0000		

Message <b>Synchronization Start / End</b>	SIA Activate PT	SIA reset PU
Parameters Area Address    CU PI Text		
Description This message is sent system synchronization starts or ends		
Comments PT00cu (Start of synchronization) PU00cu (End of synchronization)		

Message <b>Calibration Of Outputs</b>	SIA Activate BB	SIA reset BĞ
Parameters Area Address PI CU Text		
Description This message is sent for calibration of output command. There is no feedback for this command		
Comments picu0000 / BB0000		

Message <b>Sensitive fault detection mode On/Off</b>	SIA Activate BG	SIA reset MR
Parameters Area Address PI CU Text		
Description This message is sent for fault detection mode command.		
Comments picu0000 / BG0000 (on) picu0000 / BM0000 (off)		

Message <b>Lock Direction For Loop Communication</b>	SIA Activate MT	SIA reset KJ
Parameters Area Address Board (B) , Loop (L) , Direction (D) PI CU Text		
Description This message is sent for lock loop communication direction command.		
Comments picu0000 / BU0ALA (Lock NMAST Loop L in A-direction) picu0000 / BU0ALB (Lock NMAST Loop L in B-direction) picu0000 / BU0ALC (Lock NMAST Loop L in Both-direction) picu0000 / CA0ALC (UnLock NMAST Loop L) picu0000 / BU0BLA (Lock BS4, board B, Loop L in Adirection) picu0000 / BU0BLB (Lock BS4, board B, Loop L in Bdirection) picu0000 / BU0BLC (Lock BS4, board B, Loop L in Bothdir.) picu0000 / CA0BLC (UnLock BS4, board B, Loop L)		

Message <b>Activated Interlocking Input/output</b>	SIA Activate CD	SIA reset CF
Parameters Area AREA Address POINT PI Text Activation-time, input and/or output		
Description This message is sent for activated/de-activated interlocking input, output, and input/output.		
Comments riZONE / CDADDR*HH:MM, INPUTOUTPUT* (interlocking input/output activated) riZONE / CFADDR*INPUTOUTPUT* (interlocking input/output de-activated)		

## 10. COMPATIBILITY TABLE

SIA Version	Web128	Web512	WebG3	EBLWeb
I	V 1.1.0	V 2.5.0	V 1.0.0	
II	V 1.1.2	V 2.6.4	V 1.0.1	
III		V 2.6.6	V 1.1.1	V 2.0.0

## 11. TECHNICAL DATA

Hardware	Web-server II 1598, Gateway 5088			
	<b>EBL128 ≥1.1</b>	<b>EBL512 ≥2.6</b>	<b>EBL512 G3 ≥1.1</b>	<b>EBL128/EBL512 G3 ≥2.0</b>
Web-server / Gateway software	Web128	Web512	WebG3	EBLWeb
Configuration	Web128II Config Tool	Web512II Config Too	WebG3 Config Tool	EBLWin

---

DOCUMENT NAME: TECHNICAL DESCRIPTION SIA PROTOCOL IN WEB-SERVER  
DOCUMENT NUMBER: MEW02062 EN  
DATE OF ISSUE: 2016-11-07  
REV: 2  
DATE OF REVISION: 2024-04-12

**Panasonic Fire & Security Europe AB**

Jungmansgatan 12  
SE-211 11 Malmö  
SE  
Tel: +46 (0)40 697 70 00