


Panasonic Grid-Eye Evaluation Kit PAN-9520 EVB & Grid-Eye Shield

How to set up the Evaluation Kit



PC Application










- Open "Device Manager" application Click on "Network adapters" / "Ports (COM & LPT)" Search for "USB Serial Device" and note the COM port Number - in this Example "COM4"
- *In case you find several ports, please note all
 ** In case you cannot find any "USB Serial Device", check out our FAQ
 (IR Thermophile array sensor Grid-EYE | Panasonic Industry Europe GmbH)










Demonstration of Grid-Eye detection




Please swipe your hand slowly from left to right above the Grid-Eve sensor.



The Grid-Eye sensor will detect your hand and you can see the interpolation of the raw data on the right window.

Refer to the user manual for more detailed information and instructions



Webserver (View on Smartphone)

You can also connect the Grid Eye Kit with your PC/smartphone via WiFi and open the application in your browser of choice.



Grid-Eye on the browser:

After connecting, insert the following IP address on your browser: 192.168.4.1

